



1. Tent living area to prevent dust migration



2. Cut interior trim seams with a razor knife



4. Carefully remove interior casing



3. Cut Exterior seams with razor knife



5. Remove Exterior Casing



Slowly remove casing to avoid damage to the stucco or other wall surface



6. Remove old door



7. Remove old door frame



8. Temporarily position new doorframe into the old opening. Using temporary shims as a backer, Install a 3" drywall screw behind the middle hinge hidden under the weather-stripping. This will secure the frame while installing the doors, yet still allow for adjustment of the frame. Using the doors themselves in the frame is the best way to be sure the doors are fitting properly.



Using the doors “in place” carefully, adjust the frame until every thing fits perfectly before anchoring the frame permanently.

Permanently Anchoring the frame and Installing the trim